VDRO Installation on Windows 7/8/10

VDRO utilizes Microsoft Access for its database operation. If you currently do not have Access installed on your PC, you will need to install the included Access Database Engine prior to using the VDRO software.

Extract the files from the compressed folder and execute the AccessDatabaseEngine.exe file. This will start a wizard that will complete the installation. This installation can be completed either before or after the VDRO software has been installed.

Failure to complete the Access Database Engine installation will result in the VDRO software not having the ability to connect to its database.

With VDRO Version 1.1.1.0, an optional USB Relay Output module is available to control a 2 color light stack for use as a Go/No Go feature. If you have purchased this optional output module, please execute the program: SX03040001.exe included with this installation to install the necessary driver for the module.

To complete the installation of VDRO, complete the following:

1. Extract the files from the archive into a temporary folder on your PC.
2. Run the AccessDatabaseEngine.exe included in this archive.
3. If you are using the optional USB output module, run the SX03040001.exe file.
4. Run the Setup.exe file

Note: The administrative password for VDRO is: 1234

If you have any questions, please contact Accurate Technology at 800 233 0580 or 828 654 7920.