


Encoder Power Supply

The Encoder Power Supply (EPS), part number 700-1050-001, was manufactured to provide the encoder uninterrupted back up power.



Plug the encoder into the EPS. The EPS is then plugged into a readout via a 6-Pin connector cable (provided with the EPS). After fully charging (4–5 hours), the EPS provides power to the encoder for 6+ months. For the EPS to fully charge, +9 to +24 VDC must be applied as labeled on the unit.

Please consult factory if you have questions: customersupport@proscale.com or +1.828.654.7920